

③ STANDARD 3-HAND/DATE AND 3-HAND/DAY/DATE MODELS QUARTZ AND AUTOMATIC

Includes Museum Classic Automatic, 1881 Automatic men's, Red Label, SE Quartz, SE Automatic & SE Diver, select Series 800 Quartz & Series 800 Automatic, select Vizio Quartz & Vizio Automatic and Movado Heritage Series Datron & Disco Volante



FIGURE A

LEGEND:

- H – Hour hand
- M – Minute hand
- S – Seconds hand
- D – Date Window
- 1,2,3 – Crown Positions

Crown positions:

- Position 1 – Normal running position.
Crown pushed into case.
- Position 2 – To set DATE*:
Rotate crown clockwise.
- To set DAY*:
Rotate crown counterclockwise.
- Position 3 – To set TIME*:
Rotate crown in either direction.

*IMPORTANT: DO NOT set the Date on Vizio models when the time is between 9:30 PM and 3:00 AM, and automatic calendar changes are already in progress. Doing so could damage the mechanism.

*NOTE: If your watch has a screw-down crown, before you can set the Date (Day/Date) or Time, you must first unlock the crown by turning it counterclockwise approximately six rotations. After Time/Date (Day/Date) setting, the crown must be screwed back down into the case to ensure water resistance.

To manually wind an automatic movement:

- The motion of your arm during normal daily activities should be sufficient to keep the movement of your Movado automatic timepiece wound. However, if you have not worn your watch for 38 hours or more, and the watch has stopped, you will need to wind it by hand before setting the time:
1. With the crown in position 1, turn the crown clockwise approximately 20 revolutions.
 2. Reset time following instructions above.