
## (4) 3-HAND AUTOMATIC MODELS WITH DAY/DATE DISPLAY

Includes Movado Heritage Series Datron Day/Date



## **LEGEND:**

H - Hour hand

M - Minute hand

S - Seconds hand

W - Day Window

D - Date Window

1, 2, 3 - Crown positions

## Crown positions:

Position 1 – Normal running position. Crown pushed into case.

Position 2 – To set DATE:

Rotate crown clockwise.

To set DAY:

Rotate crown counterclockwise.

Position 3 – To set TIME:

Rotate crown in either direction.

- \*IMPORTANT: Do not adjust the Day or Date between the hours of 9:00 PM and 4:00 AM when automatic calendar changes are in progress, or the Day and Date may not change properly on the following day.
- \*NOTE: If your watch has a screw-down crown, before you can set the Date (Day/Date) or Time, you must first unlock the crown by turning it counterclockwise approximately six rotations. After Time/Date (Day/Date) setting, the crown must be screwed back down into the case to ensure water resistance.

## To manually wind an automatic movement:

The motion of your arm during normal daily activities should be sufficient to keep the movement of your Movado automatic timepiece wound. However, if you have not worn your watch for 38 hours or more, and the watch has stopped, you will need to wind it by hand before setting the time:

- 1. With the crown in position 1, turn the crown clockwise approximately 20 revolutions.
- 2. Reset time following instructions above.